

EZ TEE INSTALLATION GUIDE FOR DUROMAXX® SRPE



STEP 1



Core hole using EZ Tee Hole Saw.

Run drill in reverse to prevent recoil and provide a smoother edge on the cut. De-burr edges after drilling as required.

STEP 2



Insert EZ Tee Sleeve ensuring ribs are flush against the OD & ID of mainline pipe. Centerline marker should be perpendicular to pipe (12 o'clock position/top of hole).

STEP 3



Lubricate PVC Stub and inside of Boot using supplied EZ Tee Solution.

Insert Stub into the Sleeve. Align Sleeve & Stub using centerline markers. (Use of alternative lubricant may void warranty).

STEP 4



Pound PVC Stub into the Sleeve until fully seated against the "EZ Stop" ring. Use wooden block or similar substitute to evenly distribute the impact force and prevent damage to the PVC Bell.

STEP 5



Fully tighten the stainless steel clamp to complete the installation

The EZ Tee joins with a Sewer DR35 or Heavywall Sewer DR26 connection.

TOOLS NEEDED:

- EZ Tee Hole Saw (sold separately)
- Wooden Block
- Mallet

EZ Tee Diameter	DuroMaxx® SRPE Diameter
4"	30" - 120"
6"	30" - 120"
8"	30" - 120"
10"	30" - 60"
12"	30" - 60"
15"	30" - 60"

Note: Consult with your Contech Sales Engineer for tees 10" and larger for DuroMaxx 66" and larger.

EZ Tee, hole saw, and accessories are available at www.glaxyplastics.com.

