



# ChamberMaxx® Inspection and Maintenance Guide



## ChamberMaxx®

# Safety

Before entering into any storm sewer or underground retention/ detention system check to make sure all OSHA and local safety regulations and guidelines are observed during the maintenance process. Hard hats, safety glasses, steel-toed boots and any other appropriate personal protective equipment shall be worn at all times.

## **Inspection Frequency**

Inspections are recommended at a minimum annually. The first year of operation may require more frequent inspections. Frequency of inspections will vary significantly on the local site conditions. An individual inspection schedule should be established for each site.

# **Inspections**

Inspection is the key to effective maintenance and is easily performed. Inspections may need to be performed more often in the winter months in climates where sanding operations may lead to rapid sediment accumulations, or in equipment washdown areas. It is very useful to keep a record of each inspection. A sample inspection log is included for your use.

The entire treatment train should be inspected and maintained. The treatment train may consist of an upstream sump manhole, manifold system or pre-treatment HDS device. Inspections should start at the upstream device and continue downstream to the discharge orifice if incorporated into the chamber system.

#### **Pre-Treatment Device Inspection**

Inspection and maintenance procedures provided by the manufacturer should be followed for pre-treatment systems such as a CDS®, Vortechs®, VortSentry® or VortSentry® HS. Expected pollutants will be floatable trash, sediment and oil and grease. Pre-treatement devices are recommended for all detention/retention devices regardless of type.

## **Containment Row™ Inspection**

The optional Containment Row consists of a diversion concrete manhole with a weir and a drain down orifice, and a row of chambers placed on woven geotextile. The diversion weir directs the first flush flows into the Containment Row of chambers. The majority of sediment will be captured in the Containment Row due to the extended detention time which allows the particles to settle out. Higher flows overtop (bypass) the weir into the manifold system.

The Containment Row will typically be located in the first row of chambers connected to the diversion manhole. Inspection can be done through accessing the diversion manhole and visually inspecting the Containment Row through the inlet pipe. Inspection ports throughout the system can be used for visual observation and measurement of sediment accumulation using a stadia rod. When the depth of sediment accumulates over 4-inch (102 mm), cleanout is recommended.

## **Manifold System Inspection**

The main manifold pipe can be inspected from the diversion manhole upstream. When a quarter of the pipe volume has been filled with sediment the header system should be maintained.

## **Visual Inspection**

Maintenance or further investigation may be required if any of the following conditions exist:

- Evidence of an unusual amount of silt and soil build-up on the surface.
- Clogged outlet drainpipe.
- System does not drain to the elevation of the lowest pipe in dry conditions.
- Evidence of potholes or sinkholes

## Maintenance

Underground stormwater retention/detention systems should be inspected at regular intervals and maintained when necessary to ensure optimum performance. The rate at which the system collects pollutants will depend more heavily on site activities rather than the size or configuration of the system. If accumulated silt is interfering with the operation of the detention system (i.e.: blocking outlet pipes or deposits significantly reduce the storage capacity of the system) it should be removed.

It is easiest to maintain a system when there is no flow entering. For this reason, cleanout should be scheduled during dry weather.

A vacuum truck or other similar devices can be used to remove sediment from the treatment train. Starting upstream, maintain manholes with sumps and any pre-treatment devices (following manufacturer recommended procedures). Once maintenance is complete, replace all caps, lids and covers. It is important to document maintenance events on the Inspection and Maintenance Log.

## **Header System Maintenance:**

If maintenance is required, use a high pressure nozzle with rear facing jets to wash the sediments and debris into the diversion manhole. Use the vacuum hose stinger nozzle to remove the washed sediments from the sump of the diversion manhole. It is important to not flush sediments into the chamber system during the maintenance process.

#### **Containment Row™ Maintenance**

If maintenance is required, a JetVac truck utilizing a high pressure nozzle (sledge dredging tool) with rear facing jets will be required. Insert the nozzle from the diversion manhole into the Containment Row through the inlet pipe. Turn the water feed hose on and feed the supply hose until the nozzle has reached the end of the Containment Row. Withdraw the nozzle slowly.



The tool will backflush the Containment Row forcing debris into the diversion manhole sump. Use the stringer vacuum hose to remove the sediments and debris from the sump of the diversion manhole. Multiple passes may be required to fully cleanout the Containment Row. Vacuum out the diversion manhole and remove all debris. See Figure 1.

Figure 1— Containment Row shown with high pressure cleaning nozzle

# **Inspection & Maintenance Log Sample Template**

ChamberMaxx		Location:		
Date	Depth of Sediment	Accumulated Trash	Name of Inspector	Maintenance Performed/Notes

**CHAMBERMaxx** 

## SUPPORT

- Drawings and specifications are available at www.ContechES.com.
- Site-specific support is available from our engineers.

ENGINEERED SOLUTIONS
800.338.1122
www.ContechES.com

#### ©2016 Contech Engineered Solutions LLC

Contech Engineered Solutions LLC provides site solutions for the civil engineering industry. Contech's portfolio includes bridges, drainage, sanitary sewer, stormwater management, and earth stabilization products. For information, visit www.ContechES.com or call 800.338.1122.

NOTHING IN THIS CATALOG SHOULD BE CONSTRUED AS A WARRANTY. APPLICATIONS SUGGESTED HEREIN ARE DESCRIBED ONLY TO HELP READERS MAKE THEIR OWN EVALUATIONS AND DECISIONS, AND ARE NEITHER GUARANTEES NOR WARRANTIES OF SUITABILITY FOR ANY APPLICATION. CONTECH MAKES NO WARRANTY WHATSOEVER, EXPRESS OR IMPLIED, RELATED TO THE APPLICATIONS, MATERIALS, COATINGS, OR PRODUCTS DISCUSSED HEREIN. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND ALL IMPLIED WARRANTIES OF FITNESS FOR ANY PARTICULAR PURPOSE ARE DISCLAIMED BY CONTECH. SEE CONTECH'S CONDITIONS OF SALE (AVAILABLE AT WWW.CONTECHES.COM/COS) FOR MORE INFORMATION.

The product(s) described may be protected by one or more of the following US patents: 5,322,629; 5,624,576; 5,707,527; 5,759,415; 5,788,848; 5,985,157; 6,027,639; 6,350,374; 6,406,218; 6,641,720; 6,511,595; 6,649,048; 6,991,114; 6,998,038; 7,186,058; 7,296,692; 7,297,266; related foreign patents or other patents pending.